

Product Facts

We make sure



PRIMERGY rack systems Design guide

Issue March 25, 2008

Product Rack Systems

Pages 89

Introduction and highlights

Rack systems are based on the EIA-310-D 19-inch standard, according to which rack cabinets, servers and other components, such as UPSs, hubs, routers, modems and operating consoles, are manufactured. The term "standard" suggests a specification and definition of all prevalent dimensions and construction requirements relating to the mechanics and electrical equipment of these rack systems. In fact, only a few dimensions and weights are truly specified in this quasi-standard: various specifications can be interpreted too broadly, there is also a lack of tolerances in some cases, and many a dimension is not even included in the 19-inch "standard".



The problems and incompatibilities in the installation dimensions of competitor products and components from third-party vendors have always been taken into account in PRIMERGY rack systems. The PRIMECENTER rack family at the latest provides a universal and variable rack system which can accommodate most of the 19-inch components on the market without problems. Unfortunately, there will always be cases where the inaccuracy of the 19-inch standard causes problems, in particular when products from different manufacturers are to be combined.

This document is designed to facilitate the integration of PRIMERGY systems in third-party racks and the installation of third-party systems into racks from Fujitsu Siemens Computers by showing the installation requirements and the dimensions.

Contents

Introduction and highlights	1
1 Terms and conditions	4
1.1 Liability and warranty	4
1.2 Installation rules	4
1.3 Thermal qualification	4
1.4 Analyzed configurations	6
1.5 General suitability for installation	6
2 Installation dimensions	7
3 Front plate design	9
3.1 Front plate dimensions, table and drawings	9
3.2 19-inch dummy panels / blind plates	15
4 19-inch housing	18
4.1 19-inch housing dimensions	18
5 PRIMECENTER rack family	19
5.1 PRIMECENTER Rack (PCR)	20
5.2 PRIMECENTER LC-Rack 38 and 46U (liquid cooling)	20
5.2.1 Function	22
5.2.2 Zubehör	23
5.3 PRIMECENTER SME Rack	24
5.4 Remodeling kit for PRIMECENTER II rack (1100mm)	25
5.5 Enhanced tilt protection	26
5.6 Basic design of FSC racks	26
5.6.1 Vertical rack profiles	27
5.6.2 Support brackets	29
5.6.3 Space requirements	30
5.7 Layout	31
5.7.1 PCR II 940mm	31
5.7.2 PCR II 1000mm	32
5.7.3 PCR II 1100mm	32
6 PCR rack cabling	34
6.1 Cabling to and from outside	34
6.2 Cable routing between racks	34
6.3 Cable management PCR II rack (internal)	34
7 System cabling strategy	36
7.1 PCR rack cable manager	36
7.1.1 Figures	36
7.1.2 Cable routing in the cable manager	37
7.2 Cable duct for 3rd party Racks	38
7.3 Cable support	38
7.4 Cable duct 1U to trail	39
7.5 2U cable duct	40
8 Carrier system	42
8.1 Basics	42
8.1.1 Extension type	42
8.1.2 Mounting the system on telescopic rails (installation examples)	43
8.1.3 Basics of the structural design of the carrier systems for FSC, Fujitsu and third-party racks	43
8.2 Vario carrier system 714 – 786mm*	47
8.2.1 Scale drawing	47
8.2.2 Complete drawing	48
8.2.3 Vario-Träger one hand mounting	49
8.2.4 Vario-Träger mounting with centering screws	49
8.2.5 Vario-Träger mounting in round holes	50
8.3 Telescopic rail	51
8.3.1 Requirements and important dimensions	51
8.3.2 Example of telescopic rail with partial extension	53
8.4 Sliding rail	54
8.4.1 1.5mm sliding rails (design example 1)	54
8.4.2 3mm sliding rails for heavier load (design example 2)	54
8.5 Others	55
8.5.1 Horizontal mounting of PDU 32A	55
9 Accessories	56
9.1 Fastening accessories	56
9.2 Mounting elements and equipment shelves	62
9.2.1 Power supply holder RSB	62
9.2.2 Pair of sliding rails	63
9.2.3 Equipment shelf	64
9.2.4 Monitor shelf	65
9.2.5 Horizontal mounting of PDU 32A	66
10 Appendix	67
10.1 Third-party racks / older racks (structure and dimensions)	67
10.1.1 DataCenter Rack	67

10.1.2	Fujitsu rack	69
10.1.3	Classic rack	71
10.1.4	PRIMECENTER S1 Rack	73
10.1.5	Third-party racks	75
10.1.6	Example (Rittal DK Server Rack)	77
10.2	Adapter kits	78
10.2.1	Carrier systems from Classic rack -> PCR and third-party racks	78
10.2.2	Mounting examples	78
10.2.3	Carrier systems from PCR and third-party racks -> Classic rack	80
10.3	Transport rack	81
10.3.1	Transport pallet from Knürr (finish end of 2007)	81
10.3.2	Transport pallet from FSC (1/2008)	81
10.3.3	Notes on transport	83
10.3.4	Mounting tilt protection PRIMECENTER Rack (1/2008)	85
10.3.5	Setting up and leveling the rack	89

1 Terms and conditions

1.1 Liability and warranty

In principle, specific responsibilities must be observed in integrating components to create an overall system. They include compliance with country-specific and international regulations and provisions, such as electrical and electromagnetic behavior, safety regulations and operating conditions. The party integrating components from different vendors therefore bears responsibility, and is consequently liable for and warrants the integration work that has been carried out.

1.2 Installation rules

A broad range of servers means a large variety of combinations in the rack and the requirement that every server be operated within its thermal limits. To avoid every possible configuration having to be assessed separately, rules for installing servers and components in the racks have been established:

1. Every server is independent in its height unit(s) and respects the independence of neighboring servers.
2. Every server must be able to function with the resources of its height unit(s) (cooling, cable management, maintenance space, etc.).

These two rules restrict the creativity of developers of servers and rack-mounted systems to the height unit(s) required by the server, yet permit different solutions to coexist.

A thermal assessment of a server in the rack must take into account the following PRIMERGY servers cooling concept:

1.3 Thermal qualification





The following thermal conditions must be taken into account:

- A PRIMERGY server is cooled by an air current that is generated by fans within the server. Any emission of thermal energy is regarded as negligible and consequently does not contribute to cooling the server. In the same way, any possible supply of energy from thermal radiation is regarded as negligible and is ruled out.
- The front 19" plane is defined as a climatic boundary between the intake air and exhaust air of the rack or the server.

Therefore the following applies:

1. Following mounting of the server in a rack, the intake air area is defined as being the boundaries of the height units it occupies.
2. The floor and cover surfaces of the server are defined as adiabatic surfaces, i.e. thermal energy is not exchanged via the floor or ground surface. This prevents any influence from servers mounted above or below.

In cabling the server, the rack infrastructure is used optimally and the exhaust air area of the server is kept free to the maximum possible extent.



1.4 Analyzed configurations

As already indicated in the introduction, two cases are described in this document:

1. PRIMERGY servers or storage subsystems are to be integrated in racks from other manufacturers, possibly in coexistence with servers or storage systems from different vendors.
2. Servers, subsystems or infrastructure components (UPSs, switches, hubs) from third-party vendors are to be mounted in PRIMECENTER and PRIMERGY DataCenter racks.

These two cases must be viewed separately, namely with respect to:

- Installation dimensions of the systems, including cabling spaces and conditions relating to serviceability
- Cabling conditions and requirements
- Availability of mounting accessories and safety of mounting

This can result in a wide range of installation requirements. However, not all cases can be analyzed individually; the market in the 19-inch segment is simply too large. We are consequently focusing on products from Fujitsu Siemens Computers and the associated rack systems.

All PRIMERGY systems are developed on the basis of the same design principles. As a consequence, this analysis of the installation of PRIMERGY components is reduced to the essentials.

1.5 General suitability for installation


Installation of third-party products in PRIMERGY racks (EIA-310-D 19-inch standard)


2 Installation dimensions

The dimension that is guaranteed as reliable by all rack manufacturers is the installation width of 19" (Rw > 450 mm). So that this dimension can be respected in all cases, the housing width Hw is limited to a maximum of 448 mm for FSC products.

The height dimensions are guidelines for ensuring smooth installation or insertion. They are always relative to the start or the end of a height unit U (1 U = 44.45 mm).

Assuming a space of one U, the following tolerance dimensions exist:






3 Front plate design

3.1 Front plate dimensions, table and drawings

The figure and table below specify the most important dimensions for front plate design.




- Ft --- Front plate thickness (FSC) = 4mm
- Hw --- Housing width = 448mm
- Mh --- Distance between the horizontal mounting holes 465.1mm +/-1.6
- Mv --- Distance between the vertical mounting holes
- Fw --- Front plate width = 482.6mm +/-0.4
- Fh --- Front plate height
- HE/U --- Height unit = 44.45mm



The dimensions of the front plate width and the horizontal mounting holes are defined in accordance with DIN standard 41494.

Table HE/U	Fh	Mv			
1 = 44.45	42.5 +/-0	22.22 +/-0.1			
2 = 88.9	86.9 +0.4/-0	44.45 +/-0.2			
3 = 133.35	131.4 +0.4/-0	88.9 +/-0.2			
4 = 177.8	175.8 +0.4/-0	133.35 +/-0.2			
5 = 222.25	220.3 +0.4/-0	177.8 +/-0.2			
6 = 266.7	264.7 +0.4/-0	222.25 +/-0.2			


1U front plate




2U front plate

 <p>The drawing shows a 2U front plate with various dimensions and assembly details. Key dimensions include a total width of 482.6mm and a height of 86.9mm. It includes a cross-section A-A showing a slot with a width of 11.5mm and a depth of 1.5mm. The plate has a central handle area with a width of 129.6mm and a height of 15mm. The bottom edge features a series of mounting holes with a spacing of 21.725mm and a total width of 86.9mm. The plate is designed for a 2U server rack.</p>	 <p>The isometric view shows the 3D structure of the front plate, highlighting its L-shaped profile and the mounting points for screws. The plate is shown in a perspective view, illustrating its depth and the placement of the handle and mounting holes.</p>
<p>Generally, the following applies: Front plate 2U server b = 482.6mm ±0.4 h = 86.9mm +0.4/-0 (Housing: h = 84.9mm +1.5/-∞)</p>	<p>Bending radius: R1 Radii without dimensions: R2 Chamfers without dimensions: 2 x 45°</p> <p>Stamping direction free Part degreased Edges free of burr</p> <p>○ = Test dimension Tolerance of coordinate dimensions +/-0.1</p>


3U front plate



Logos front plate



[1] Polyesterfoil Autotex V280-280my+
3M Scotch 9672-130my
Label Thickness: 0,4mm
Total Thickness: 0,6mm



[1] Polyesterfoil Autotex V280-280my+
3M Scotch 9672-130my
Label Thickness: 0,4mm
Total Thickness: 0,6mm

3.2 19-inch dummy panels / blind plates


Front plates are also available as so-called covers, dummy panels or blind plates for closing empty bays and slots in the rack. This is mandatory to ensure proper ventilation of the installed servers in the rack.

By default the following cover plates are available:



19" Kabeldurchführung 1HE mit Bürsten





19" Kabeldurchführung 1HE mit Bürsten



19" cable bushing 1U with strip
S26361-F2735-E25; S26361-F2735-L25

<p>Dummy panel 1U tool-less</p>  <p>Technical drawing of a dummy panel 1U tool-less. The drawing shows three views: a front view, a side view, and a top view. The front view shows a rectangular panel with a dashed line indicating the internal structure. The side view shows the panel's profile with dimensions: 12, 12.5, 2.2, 13.5, 2.7, 10, 2.7, 20, 11.6, 6.6, 10.1, 42.8±0.2, 482.6±0.4, and 466. The top view shows the panel's width with dimensions: 9+0.2, 2.7, 2.7, 11.6, 6.6, 10.1, 42.8±0.2, 482.6±0.4, and 466.</p>	<p>Dummy panel 1U tool-less</p>  <p>A 3D perspective view of the dummy panel 1U tool-less, showing its rectangular shape and the mounting mechanism at the bottom.</p>
<p>dummy panel 1U plastic, tool-less mounting (Kunststoff: >PC+ABS< -FR(40) SN 614 UL 94 V0)</p> <p>S26361-F2735-L130 A3C40088113</p>	

<p>Dummy panel 2U tool-less</p>  <p>Technical drawing of a dummy panel 2U tool-less. The drawing shows the panel from the front and side views. Key dimensions include: top edge width 12, top edge hole diameter 9^{+0,2}, top edge hole offset 2, top edge hole radius R2, top edge hole offset 12,5, top edge hole offset 2,2, top edge hole offset 13,5, top edge hole offset 9, top edge hole offset 2, top edge hole offset 10, top edge hole offset 466, top edge hole offset 87,3±0,2, top edge hole offset 482,6±0,4, top edge hole offset 10,1, top edge hole offset 11,6, top edge hole offset 6,6, top edge hole offset 44,45, top edge hole offset 2,7.</p>	<p>Dummy panel 2U tool-less</p>  <p>Photograph of the dummy panel 2U tool-less. The panel is shown in a vertical orientation, highlighting its slim profile and the mounting brackets at the bottom.</p>
<p>dummy panel 2U plastic, tool-less mounting (Kunststoff: >PC+ABS< -FR(40) SN 614 UL 94 V0)</p> <p>S26361-F2735-L131 A3C40088114</p>	

4 19-inch housing

The term 19-inch housing refers to all system installation components of this format.

4.1 19-inch housing dimensions

The form and the housing depth depend in each case on the corresponding carrier system and the rack (installation depth) into which the housing is installed. This chapter will not consider these factors but will only show the theoretical limits. For more information see the sections on rack types and carrier systems.





Table 2

U	Hh	Fh	Mv	Hd (PCR1000)	Hd (PCR1100)
1 = 44.45	40.5 +3/-∞	42.5 +1/-0	22.22 +/-0.1	782mm	792mm
2 = 88.9	84.9 +1.5/-∞	86.9 +0.4/-0	44.45 +/-0.2	782mm	792mm
3 = 133.35	129.4 +0/-∞	131.4 +0.4/-0	88.9 +/-0.2	782mm	792mm
4 = 177.8	173.8 +0/-∞	175.8 +0.4/-0	133.35 +/-0.2	782mm	792mm
5 = 222.25	218.3 +0/-∞	220.3 +0.4/-0	177.8 +/-0.2	782mm	792mm
6 = 266.7	262.7 +0/-∞	264.7 +0.4/-0	222.25 +/-0.2	782mm	792mm

Note: 1U 19-inch housings are subject to slightly different special rules concerning the distance between the housing top and bottom and the height unit.



5 PRIMECENTER rack family



This chapter describes the different FSC rack types with their installation dimensions and requirements.



PRIMECENTER rack family



*The figure does not show the 48 U rack ((Should there be a corresponding asterisk in the text or is this just a note?))

5.1 PRIMECENTER Rack (PCR)


	
PRIMECENTER II Rack 12U / 1x2U vertical S26361-K826-V101 / D:GPRAC-BG50	t1 = 1000mm b = 700mm h = 670mm t2 = 1200mm weight = 82kg <u>Transport dimensions:</u> t = 1180mm b = 775mm h = 790mm
PRIMECENTER II Rack 24U / 2x2U vertical S26361-K826-V102 / D:GPRAC-BG51 S26361-K826-V212	t1 = 1000mm b = 700mm h = 1220mm t2 = 1200mm weight = 110kg <u>Transport dimensions:</u> t = 1180mm b = 775mm h = 1345mm t1 = 1100mm b = 700mm h = 1220mm t2 = 1315mm weight = 112kg <u>Transport dimensions:</u> t = 1280mm b = 775mm h = 1345mm
PRIMECENTER II Rack 38U / 3x2U vertical S26361-K826-V103 / D:GPRAC-BG52 S26361-K826-V213	t1 = 1000mm b = 700mm h = 1825mm t2 = 1200mm weight = 150kg <u>Transport dimensions:</u> t = 1180mm b = 775mm h = 1935mm t1 = 1100mm b = 700mm h = 1825mm t2 = 1315mm weight = 152kg <u>Transport dimensions:</u> t = 1280mm b = 775mm h = 1935mm
PRIMECENTER II Rack 46U / 3x2U vertical S26361-K826-V104 / D:GPRAC-BG53 S26361-K826-V214	t1 = 1000mm b = 700mm h = 2220mm t2 = 1200mm weight = 168kg <u>Transport dimensions:</u> t = 1180mm b = 775mm h = 2335mm t1 = 1100mm b = 700mm h = 2220mm t2 = 1315mm weight = 171kg <u>Transport dimensions:</u> t = 1280mm b = 775mm h = 2335mm

5.2 PRIMECENTER LC-Rack 38 and 46U (liquid cooling)


--	--

													
<p>PRIMECENTER LC-Rack 38U / 31U nutzbar, 2x2U vertikal Three-way valve</p> <p>S26361-K1022-V130</p>	<table><tr><td><u>t1 = 1200mm</u></td><td>b = 700mm</td><td>h = 1800mm</td></tr><tr><td>t2 = 1400mm</td><td>weight = 88kg</td><td></td></tr><tr><td colspan="3"><u>Transport dimensions:</u></td></tr><tr><td>t = 1300mm</td><td>b = 800mm</td><td>h = 1900mm</td></tr></table>	<u>t1 = 1200mm</u>	b = 700mm	h = 1800mm	t2 = 1400mm	weight = 88kg		<u>Transport dimensions:</u>			t = 1300mm	b = 800mm	h = 1900mm
<u>t1 = 1200mm</u>	b = 700mm	h = 1800mm											
t2 = 1400mm	weight = 88kg												
<u>Transport dimensions:</u>													
t = 1300mm	b = 800mm	h = 1900mm											
<p>PRIMECENTER LC-Rack 38U / 31U nutzbar, 2x2U vertikal Three-way valve and socket with roles</p> <p>S26361-K1022-V135</p>	<table><tr><td><u>t1 = 1200mm</u></td><td>b = 700mm</td><td>h = 1800mm</td></tr><tr><td>t2 = 1400mm</td><td>weight = 98kg</td><td></td></tr><tr><td colspan="3"><u>Transport dimensions:</u></td></tr><tr><td>t = 1300mm</td><td>b = 800mm</td><td>h = 2008mm</td></tr></table>	<u>t1 = 1200mm</u>	b = 700mm	h = 1800mm	t2 = 1400mm	weight = 98kg		<u>Transport dimensions:</u>			t = 1300mm	b = 800mm	h = 2008mm
<u>t1 = 1200mm</u>	b = 700mm	h = 1800mm											
t2 = 1400mm	weight = 98kg												
<u>Transport dimensions:</u>													
t = 1300mm	b = 800mm	h = 2008mm											
<p>PRIMECENTER LC-Rack 46U / 40U nutzbar, 2x2U vertikal Three-way valve</p> <p>S26361-K1022-V230</p>	<table><tr><td><u>t1 = 1200mm</u></td><td>b = 700mm</td><td>h = 2200mm</td></tr><tr><td>t2 = 1400mm</td><td>weight = 92kg</td><td></td></tr><tr><td colspan="3"><u>Transport dimensions:</u></td></tr><tr><td>t = 1300mm</td><td>b = 800mm</td><td>h = 2300mm</td></tr></table>	<u>t1 = 1200mm</u>	b = 700mm	h = 2200mm	t2 = 1400mm	weight = 92kg		<u>Transport dimensions:</u>			t = 1300mm	b = 800mm	h = 2300mm
<u>t1 = 1200mm</u>	b = 700mm	h = 2200mm											
t2 = 1400mm	weight = 92kg												
<u>Transport dimensions:</u>													
t = 1300mm	b = 800mm	h = 2300mm											
<p>PRIMECENTER LC-Rack 46U / 40U nutzbar, 2x2U vertikal Three-way valve and socket with roles</p> <p>S26361-K1022-V235</p>	<table><tr><td><u>t1 = 1200mm</u></td><td>b = 700mm</td><td>h = 2200mm</td></tr><tr><td>t2 = 1400mm</td><td>weight = 102kg</td><td></td></tr><tr><td colspan="3"><u>Transport dimensions:</u></td></tr><tr><td>t = 1300mm</td><td>b = 800mm</td><td>h = 2408mm</td></tr></table>	<u>t1 = 1200mm</u>	b = 700mm	h = 2200mm	t2 = 1400mm	weight = 102kg		<u>Transport dimensions:</u>			t = 1300mm	b = 800mm	h = 2408mm
<u>t1 = 1200mm</u>	b = 700mm	h = 2200mm											
t2 = 1400mm	weight = 102kg												
<u>Transport dimensions:</u>													
t = 1300mm	b = 800mm	h = 2408mm											

5.2.1 Function



5.2.2 Zubehör





connecting kit:

- 1 x Kugelhahn m. Entl. DN 25
- 1 x Entleerkugelhahn 1/4"
- 1 x Hydrocontrol DN25 m Entl.Mnip
- 2 x Flex-Schlauch DN 25,L=1,5m
- 4 x Nippel MS (flachdichtend) 1"

connecting kit 1,5 m LC Racks optional
 product number: S26361-F2735- L602
 delivery unit: A3C40097585


5.3 **PRIMECENTER SME Rack**
(SME / small medium enterprise)

<p>SME rack</p> 	<p>SME rack</p> 
<p>PRIMECENTER SME Rack 24U S26361-F3327-L24</p>	<p>t = 1000mm b = 700mm h = 1220mm weight = 35kg</p> <p><u>Transport dimensions:</u> t = 1270mm b = 775mm h = 1380mm</p>
<p>PRIMECENTER SME Rack 42U S26361-F3327-L42</p>	<p>t = 1000mm b = 700mm h = 1950mm weight = 70kg</p> <p><u>Transport dimensions:</u> t = 1270mm b = 775mm h = 2000mm</p>

5.4 Remodeling kit for PRIMECENTER II rack (1100mm)


Instruction manual
Remodeling kit for PRIMECENTER II rack from 1000 to 1100mm depth.

PCR II Rack 1000mm




Picture 1

Remodeling kit






Picture 2

Remodeling



Picture 3





product number:

PCR II 24U S26361-F2735-L212

PCR II 38U S26361-F2735-L213

PCR II 46U S26361-F2735-L214

5.5 Enhanced tilt protection




OLD



Enhanced tilt protection
S26361-F2735-L210 A3C40091899

NEW

Dimensions :
T = 1214,5mm b = 696mm h = 22,5mm

5.6 Basic design of FSC racks















Carrier profiles: dimensioned sketch and structure

5.6.1 Vertical rack profiles


FSC PCRII	
-----------	--

	 <p>2.5 mm steel profile</p> <p>HEU 4</p> <p>HEU 3</p> <p>HEU 2</p> <p>HEU 1</p>
 <p>9.5 x 9.5mm</p> <p>U 3</p> <p>U 2</p> <p>44,45 mm</p> <p>U 1</p> <p>U 0</p> <p>7</p> <p>27 mm ^{+0,5}₋₀</p> <p>9 mm</p> <p><i>FSC PCR II Rack</i></p> <p><i>Classic Rack</i></p> <p><i>DataCenter Rack</i></p> <p><i>Primecenter Rack 1</i></p> <p><i>FJ Rack</i></p> <p>free area for mounting kits</p>	 <p>15</p> <p>2.5</p> <p>61.5</p> <p>7</p> <p>42</p>
<p>vertical extrusion with mounting holes 9.5x9.5mm (EIA-310-D Standard)</p>	<p>FSC PRIMECENTER Rack II 19" (PCR II)</p>


5.6.2 Support brackets

	<p>NEW Q2 2008</p> 
<p>Support bracket 1U (max. 15kg)</p> <p>D:GPRAC-ZB5211; S26361-F2735-E10 / L10</p>	<p>enhanced support bracket 1U (max. 15kg)</p> <p>D:GPRAC-ZB5211; S26361-F2735-E10 / L10</p>
	<p>NEW Q2 2008</p> 
<p>Support bracket 2U (max. 35kg)</p> <p>D:GPRAC-ZB5212; S26361-F2735-E15 / L15</p>	<p>enhanced support bracket 2U (max. 35kg)</p> <p>D:GPRAC-ZB5212; S26361-F2735-E15 / L15</p>
	<p>New design</p>  <p>A3C40098028</p>
<p>Support bracket 3U (max. 50kg)</p> <p>D:GPRAC-ZB5215; S26361-F2735-E31 / L31</p>	<p>Support bracket 3U (max. 50kg)</p> <p>D:GPRAC-ZB5215; S26361-F2735-E31 / L31</p>

5.6.3 Space requirements




- 1 - Operational Clearance Area front- and rear side 700 x 700mm**
- 2 - Service Area front side 1500mm (b) x 1200mm (t)
area required to install and remove systems to / from Rack**
- 3 - Service Area rear side 1500mm (b) x 1000mm (t)
area required to install the cabling and power line**
- 4 - Service Area of both side 400mm (b) x 1000mm (1100mm) (t)**
- 5 - Kippschutz / tilting protection
(240x700mm / 390x700mm)**




5.7 Layout

5.7.1 PCR II 940mm




Version discontinued 2005

5.7.2 PCR II 1000mm




5.7.3 PCR II 1100mm

PCR1100




6 PCR rack cabling


6.1 Cabling to and from outside




6.2 Cable routing between racks



6.3 Cable management PCR II rack (internal)





7 System cabling strategy



7.1 PCR rack cable manager

The cable management element is a patented component of Fujitsu Siemens Computers and Knürr. It is used in the DataCenter and PRIMECENTER racks. Unlike conventional cable guides, the cable management is an integral part of the rack and not of the systems that are installed in the rack. This means it can be mounted in the rack types listed above for any assembly from any manufacturer ≥ 2 height units. The articulated cable guide can be mounted in a 1U grid. This compatibility allows consistent rack cabling.

The functional principle is based on an articulated cable guide which is mounted on a carrier plate in such a way that it can be folded in and out. The articulated cable guide follows the installed rack components half-way. The cables are routed in the comb-like cable guide and screwed to the system component.

7.1.1 Figures

Figure 1



rdg150

The figure shows the cable manager in its idle position.

Figure 2






Figure 3




rdg152

Cable manager with articulated cable guide folded out


Cabel management PCR Rack
SNP:SY-F2262L20-P; D:GPRAC-ZB527; S26361-F2735-E7 / L7

7.1.2 Cable routing in the cable manager

The following example shows how the cables are routed in the cable manager:



7.2 Cable duct for 3rd party Racks



Cable duct for 3rd party Racks (mounting on right or left side)

Produktnummer: S26361-F2201- E20 / L20

Liefereinheit: A3C40058445

7.3 Cable support



raceway PCR II


S26361-F2735-E20

S26361-F2735-L20


The cable guide accommodates and holds cable harnesses. Like the cable management element, it can be mounted in the 1U grid of the rack.

7.4 Cable duct 1U to trail


mounting



step 1
dismount bolts
from the vario carrier




step 2
mounting
cableduct



A3C40097047





step 3
mounting
cable connector on the telescopic rail



step 4
cabling
cableduct


Cable duct 1U
S26361-F2735- E8 / L8
A3C40086204

Examples of cabling



7.5 2U cable duct

--





Cable hinge arm with bushing
D:GPRAC-ZB523

8 Carrier system

8.1 Basics

As well as in a fixed installation, the 19" rack components can also be mounted on sliding or telescopic rails which allow them to be pulled out of the rack. The ball-bearing telescopic rails are available in two different versions.


8.1.1 Extension type

<div><p>Telescopic rail – full extension: The telescopic rail has three main components (inner, center and outer rail). Extension depth >105%</p><p>Telescopic rail full extension >105%</p></div>	<div><p>Telescopic rail - partial extension: The telescopic rail has two main components (inner and outer rail). Extension depth approx. 50%</p><p>Telescopic rail partial extension</p></div>
Full extension	Partial extension


8.1.2 Mounting the system on telescopic rails (installation examples)

There are three primary ways of mounting systems on telescopic rails:


- 1. Sliding the system onto a system support plate and securing it.
- 2. Screwing the system directly to the inner telescopic rail. In this case, you replace the system by separating the rails.
- 3. There are shoulder screws on the system housing which engage in the keyholes of the inner telescopic rail.



System mounted on system support plates (high safety during mounting!)



System screwed directly to the telescopic rail







System with shoulder screw for keyhole engagement / KEYHOLE
Shoulder screw M4 Torx T20 A3C40071737





8.1.3 Basics of the structural design of the carrier systems for FSC, Fujitsu and third-party racks





A basic requirement for designing carrier systems is compliance with the EIA-310-D 19-inch standard and information on the different carrier profiles on the market.

FSC PCR rack and most third-party racks

FSC PCR rack and most third-party racks	
---	--


	 <p>2.5 mm steel profile</p>
 <p>9.5 x 9.5mm</p> <p>U 3</p> <p>U 2</p> <p>44.45 mm [1.750"]</p> <p>U 1</p> <p>U 0</p> <p>7</p> <p>27 mm $+0.5$ -0 FSC PCR II Rack</p> <p>9 mm</p> <p>Classic Rack DataCenter Rack Primecenter Rack 1 FJ Rack</p> <p>free area for mounting kits</p>	 <p>15</p> <p>2.5</p> <p>61.5</p> <p>7</p> <p>42</p>
<p>vertical extrusion with mounting holes 9.5 x 9.5 ± 0.1mm (EIA-310-D Standard)</p>	<p>FSC PRIMECENTER Rack II 19" (PCR II) [9.5mm ± 0.1 = 0.375 ± 0.004" square]</p>

<p>FSC DCR rack and Fujitsu rack</p> 	 <p>2 mm Alu Stranggussprofil</p>
<p>vertical extrusion with mounting holes 9 x 9mm</p>	<p>FSC DataCenter rack; Fujitsu rack; Knürr miracel rack</p>
<p>FSC and Knürr Classic rack</p> 	 <p>2 mm Alu Stranggussprofil</p>
<p>vertical extrusion with T-slot</p>	<p>FSC Classic Rack</p>

<p>US 6mm</p> 	<p>US 6mm</p> 
<p>19" rack vertical profile (US) 6mm / 0.24" Ø</p>	<p>[HP Rack 7.1 ±0.1mm / 0.28 ±0.004" Ø]</p>
<p>US 8.5mm</p> 	<p>US 8.5mm</p> 
<p>19" rack vertical profile (US) 8.5 ±0.1mm Ø</p>	<p>(8.5mm = 0.33")</p>


8.2 Vario carrier system 714 – 786mm*

8.2.1 Scale drawing




A3C00291125

8.2.2 Complete drawing




8.2.3 Vario-Träger one hand mounting

one hand mounting in a EIA-310-D standard rack




front side






back side

8.2.4 Vario-Träger mounting with centering screws




8.2.5 Vario-Träger mounting in round holes

mounting vario carrier in US racks with round holes




mounting the vario carrier on the back side from the rack with M5 screws




mounting the vario carrier on the front side from the rack with M5 screws

8.3 Telescopic rail


8.3.1 Requirements and important dimensions




Position of the telescopic rail on the Vario carrier relative to the 19-inch installation plane
(top view)



Position of 13mm telescopic rail relative to U




Position of 10mm telescopic rail relative to U



Position of 10mm telescopic rail (partial extension) relative to U


8.3.2 Example of telescopic rail with partial extension

Carrier system 1U



Carrier for server with shoulder screw M4 – partial extension slide

Carrier system 1U




Carrier for server with shoulder screw M4 – partial extension slide


8.4 Sliding rail

Sliding rails are used for static installation of rack components which are completely removed from the rack for service and maintenance. They do not allow the component to be pulled out completely and, in special cases, provide tilt protection and a stopper. Based on the Vario carrier, they are designed as different versions for the specific areas of use.

8.4.1 1.5mm sliding rails (design example 1)



8.4.2 3mm sliding rails for heavier load (design example 2)



8.5 Others

8.5.1 Horizontal mounting of PDU 32A



Einbausatz PDU 32A





Horizontal 19"





A3C40076828





S26361-F2262-E301 / L301

9 Accessories


9.1 Fastening accessories

	
	
<p>Zentrierbefestigung M5 Torx T20 Centering screw M5 Torx T20 A3C40063207</p>	<p>Haltebolzen M5 / bolt M5 A3C40088218</p>


	
	
<p>Zentrierschraube M5 Torx T20 Centering screw M5 Torx T20 A3C40077379</p>	<p>Zentrierschraube M5 II Torx T20 Centering screw M5 II Torx T20 A3C40095430</p>

	
	
<p>Ansatzschraube M4 Torx T20 Shoulder screw M4 Torx T20 A3C40071737</p>	<p>Käfigmutter M5, Käfigmutternsatz M5 (50Stck) Cage nut M5 0007000120</p> <p>S26361-F2735-L500</p>


Zentrierscheibe II.bmp




Zylinderschraube M5x10.bmp



Zentrierscheibe II_02.wmf



Zylinderschraube M5x10_02.wmf




Zentrierscheibe II
Centering washer II
A3C40063203

Zylinderschraube M5x10 Torx T20
Pan head screw M5x10 Torx T20
9601310021


Federmutter M5.bmp




zs_01.bmp



Federmutter M5_02.wmf




Zs_01.wmf




Federmutter M5
Spring nut M5
A3C40014728

Zentrierscheibe für 1U Kabelarm
Centering washer 1U cable duct
A3C40082271

DUZ lock M6









Cable guide



Mounting system for dummy panel
screw M6 A3C40066469
crank A3C40066468





Cable guide, x5
D:GPRAC-ZB5501

Two universal mounting plates are available for mounting different multiple-socket outlets. They can be mounted in the 19-inch grid and in any free position on the spring grooves of the carrier profiles.


<p>Mounting plate for 1 multiple-socket outlets</p> 	<p>Mounting plate 2 for multiple-socket outlets</p> 
<p>Mounting plate 1 for multiple-socket outlets</p> 	<p>Mounting plate 2 for multiple-socket outlets</p> 
<p>Mounting plate 1 for multiple-socket outlets</p> <p>Example: Combination of mounting plate 1 and 2 PDU 32A</p> 	<p>Mounting plate 1 for multiple-socket outlets</p> 
<p>Mounting plate 1 multiple-socket outlets</p> <p>A3C40037444</p>	<p>Mounting plate 2 multiple-socket outlets</p> <p>A3C40040453</p>

9.2 Mounting elements and equipment shelves


9.2.1 Power supply holder RSB

<p>PS holder RSB</p> 	<p>PS holder RSB</p> 
<p>PS holder RSB</p> 	<p>PS holder RSB</p> 
<p>PS-holder RSB A3C40065479</p>	

9.2.2 Pair of sliding rails




9.2.3 Equipment shelf



equipment floor
S26361-F1609-E35 / S26361-F1609-L135

9.2.4 Monitor shelf




monitor floor

S26361-F1609-E17 / S26361-F1609-L17

9.2.5 Horizontal mounting of PDU 32A

Carrier left PDU 32A
2 x S26361-F2262-E132 / L132 or
1 x S26361-F2262-E332 / L332

Carrier right PDU 32A
2 x S26361-F2262-E132 / L132 or
1 x S26361-F2262-E332 / L332



mounting kit PDU 32A (horizontally)
S26361-F2262-E301 / S26361-F2262-L301


10 Appendix

10.1 Third-party racks / older racks (structure and dimensions)

10.1.1 DataCenter Rack

Since 2002, the DataCenter rack (depth: 900mm) has been the standard rack for PRIMERGY servers in the FSC portfolio. At the end of 2002 it was replaced by the PRIMECENTER S2 rack and was available in the following versions:

Layout




DataCenterRack

Frontansicht / Frontal view

rdg008



Carrier profile



DataCenterRack

Rw --- Rack Einbaubreite / Rack width = 450,5mm +1

rdg006b




2 mm Alu Stranggussprofil

Figure: Vertical carrier profile in 1U DataCenter rack


10.1.2 Fujitsu rack

Layout



Fujitsu Rack 2007

Carrier profile



DataCenterRack

Rw --- Rack Einbaubreite / Rack width = 450,5mm +1

rdg006b






Figure: Vertical carrier profile in 1U DataCenter rack

2 mm Alu Stranggussprofil

10.1.3 Classic rack

The Classic rack is based on the **Miracel** rack system from the company Knürr AG. It was the first standard rack in the FSC portfolio for integrating 19-inch components. In 2000, it was replaced by the DataCenter rack.

Layout





Frontansicht / Frontal view

Classic Rack

rdg007



Carrier profile



Classic Rack

Rw --- Rack Einbaubreite / Rack width = 450,5mm +1

rdg006




2 mm Alu Stranggussprofil

Figure: Vertical carrier profile in 1U Classic rack


10.1.4 PRIMECENTER S1 Rack

The PRIMECENTER S1 rack was developed by FSC and was the standard rack for RM systems, BS2000 and Primepower servers for several years. At the end of 2002 it was replaced by the PRIMECENTER S2 rack.


Layout



Carrier profile




PRIMECENTER Rack S1



Rw --- Rack Einbaubreite / Rack width = >450mm

rdg006d


Trägerprofil Primcenter 1 Rack



10.1.5 Third-party racks

Rack dimension table

1	Rack front	A	Rack depth	C	Installation plane clearance
2	Rack rear	B	Rack width	C1	Front installation plane
D	Cabling space	E	Front plate design/Air-conditioning	C2	Rear installation plane
F	Carrier system space l/r	P	PRIMERGY installation depth		
a1/b1/a2/b2	Support uprights				



The following figures show an example of the typical structure of a 19" third-party rack for servers.




Frontansicht



Seitenansicht

740




Rückseite

Einbaugrundfläche
für 19" Komponenten

Frontseite


450

19" Vertikal-
träger HR19" Vertikal-
träger HL19" Vertikal-
träger VR19" Vertikal-
träger VL

Basisaufbau eines Third Party Racks

Beispiel: Höhe 5HE und 1HE Tragewinkel (1HE = 44,45mm)


rdg019



rdg018

10.1.6 Example (Rittal DK Server Rack)

Layout



Rittal DK Server Rack


rdg007c

10.2 Adapter kits

10.2.1 Carrier systems from Classic rack -> PCR and third-party racks

The adapter kit S26361-F2734-L14 is used for mounting older support systems which are exclusively designed for the Knürr attachment grid. At the same time it allows devices to be mounted in the PRIMECENTER and third-party racks, as it exclusively uses the square 19" grid for mounting.


Knürr adapter kit




Adapter Kit 1 (Knürr -> DC / PCR)
A3C40038779 S26361-F2734-L14

10.2.2 Mounting examples


Example 1



Example 2




Example 3 shows the reconstruction of the Knürr side brackets for mounting older carrier systems



Position of the parts from Adapter Kit 1 (Knürr -> DC/PCR) A3C40038779 S26361-F2734-L14 In PCR II Rack


Example 2 shows the reconstruction of the side grid with a 1U support bracket. The top support bracket in the figure shows the model from the DataCenter rack.




rdg020b

10.2.3 Carrier systems from PCR and third-party racks -> Classic rack

Telescopic rail carrier | Classic rack



Telescopic rail carrier | Classic rack




Installation dimensions

Telescopic rail carrier II Classic rack (Teleskopschienträger II Classic Rack a.bmp)



Telescopic rail carrier II Classic rack



Installation dimensions

Telescope rail carrier II classic rack

A3C40063238 in Adapter Kit I Classic Rack S26361-F1331-L200 / S26361-F1331-L300

10.3 Transport rack

10.3.1 Transport pallet from Knürr (finish end of 2007)

Handhabungs- und Transportanweisung
Hinweise zu Transport, Lagerung und Sicherheitshinweise umseitig
Handling and Transportation Instructions
Notes on transportation, storage, and safety instructions overleaf

Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




Figure 6




Figure 7






Figure 8




Remodeling



10.3.2 Transport pallet from FSC (1/2008)

Handhabungs- und Transportanweisung
Hinweise zu Transport, Lagerung und Sicherheitshinweise umseitig
Handling and Transportation Instructions
Notes on transportation, storing, and safety instructions overleaf



10.3.3 Notes on transport

Detaching from the wooden pallet

- The unit is seated on the pallet and is secured with 6 metal clamps, which must be unscrewed from the pallet.
- To remove the screws you need a Phillips screwdriver.
- Once the packaging foil has been removed, the unit must be slid off the pallet as shown above.

Transportation and storage


- The following mechanical and climatic environmental conditions according to EN 60721-3-1 and -3-2 must be observed:
 - **Storage:** **Product class 1M3 / 1K2 1S2**
 - **Transport:** **Product class 2M2 / 2K2 2S1**
- Attention: When transporting the unit, make sure it does not tilt more than 30°.
- The unit must remain in its original packaging until it reaches the installation location.

Safety instructions


Before components are pulled out or started up, the anti-tilt plate must be installed.

For further important notes on the rack see the Technical Manual “Rack System”, chapter 2. You will find the manual in the accessory pack inside the rack.


TP_16.wmf




TP_15d.wmf




TP_15c.wmf





TP_15b.wmf




10.3.4 Mounting tilt protection PRIMECENTER Rack (1/2008)





- 1 Klemmmutter M5
- 2 Befestigungskralle
- 3 screw Innensechskantschraube M5x8mm
- 4 screw Innensechskantschraube M8x12mm







screw M5x8mm (right side Rack)
tool: Innensechskantschlüssel M4




screw M8x12mm
tool: Innensechskantschlüssel M6





screw fixieren



10.3.5 Setting up and leveling the rack

